



ADD-PIC

Introduction:

The ADD-PIC adapter allows you to add DIP8, DIP14, DIP18, DIP28 and DIP40 sockets to program PIC microcontrollers with programmers lacking tulip sockets and only equipped with a SPI connector such as the PRESTO. It is also provided with a connector allowing you to insert it into a smartcard programmer such as the CAR-07 or INFINITY-UNLIMITE.

It is also possible to use the ADD-PIC as a prototyping board.

Item includes:

PC board with tulips sockets.
User manual in English and French.